

# Rittal – The System.

Faster – better – everywhere.

## Hygienic Design Enclosures

Superior Cleanability



ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES



FRIEDHELM LOH GROUP

# Rittal – The System.

Faster – better – everywhere.

## One-stop shop for multiple solutions and optimum processes

Different enclosure solutions are needed for the various locations inside a food and beverage production facility. From enclosures that can withstand frequent washdowns on the factory floor to the IT infrastructure in the data center, Rittal has the right solution to protect your sensitive controls and electronic equipment.

**Hygienic design compact enclosures** can be wall mounted with the HD system accessories.

**Hygienic design control and monitoring, consoles, and support arms.**

**Hygienic design large system enclosures and accessories.**

**Climate control outside the hygiene zone**

Rittal Chillers can supply the air/water heat exchangers in the hygiene zone and the LCP in the data center with the required cooling water.

**Edge Data Center**

IT infrastructure for maximum computing power with short latencies, located close to the production.

**Air to Water Heat Exchangers**

keep your systems cool using in-house chilled water or Rittal water chillers. No more clogged filters or replacing dirty filters.

**Hygienic Design Compact Enclosures and Terminal Boxes**

can be machine mounted with the HD system accessories.

**TS8 Enclosure System**

Enclosures and climate control solutions for outside the washdown or hygienic zone. Available in Stainless Steel or Carbon Steel.

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES



# Hygienic standards for high productivity and reliability

“Rittal – The System.” stands for cleverly thought-out system solutions for hygienic production in the food industry. Particularly in open processes, where the resistance of the gasket to detergents and disinfectants is crucial, it is vital for the production plant to be equipped with optimized enclosures, terminal boxes and command panels.



## The Rittal Hygienic Design for food safety is based on:

### European standards and directives

- EN 1672-2-2009-07 Food machinery/General design principles/ Part 2: Hygiene requirements
- EN ISO 14 159:2008-07 Safety of machinery – Hygiene requirements for the design of machinery
- EN 16001:2009-06 Energy management to improve energy efficiency
- Machinery directive 2006/42/EC binding
- Document 13 EHEDG guideline on the hygienic design of apparatus for open processes, prepared in collaboration with 3-A and NSF International

### EU regulations

- 852/2004 on the hygiene of raw materials and food products
- 853/2004 specific hygiene rules for food of animal origin
- 854/2004 specific rules for the organization of official controls on products of animal origin intended for human consumption
- 1935/2004 on materials and articles intended to come into contact with food

Decide for yourself what is important.


### Rittal Hygienic Design boosts operational hygiene

- Reduces the use of C&D agents
- Optimizes cleaning results
- Ensures higher productivity
- Minimizes risks
- Increases energy efficiency (CO2 footprint)

All terminal boxes and compact enclosures are cULus listed.

The DGUV test certificates are valid for the following products:

- NV 16201 terminal boxes HD
- NV 13091 compact enclosures HD
- NV 17040 air/water heat exchangers HD



# Cleanliness assured

Terminal boxes and compact enclosures in Hygienic Design (HD) are key elements in the design of open processes in the food industry and clean rooms due to their ease of cleaning and inspection. Compatible accessories such as wall spacer brackets and HD-compatible cable glands complete the range. If you have specific requirements, "Rittal – The System." is sure to have the right solution.



Hygienic Design terminal boxes and compact enclosures are crucial elements when designing open processes in the food and beverage industry and for hygienic zones where ease of cleaning is crucial.

**1** Silicone gasket: Highly resistant to aggressive detergents, hot water, high pressure, and can be easily replaced in minutes

**2** Inclined roof: Prevents pooling of liquids, and ensures that surfaces are readily visible

**3** Slot-free design – No hollow spaces between the enclosure and door

**4** Fine brushed surface finish makes it easier to clean: Fully sealed enclosures with a uniform 400 grain size brushed finish for a uniform surface roughness of  $< 8 \mu\text{m}$

**5** Easy-to-clean lock system: Tailored to the requirements of the food and consumables industry

**6** Interior installation:  
 – Attachment points for fitting interior installation rails, for individual installation in the depth with HD compact enclosures  
 – HD terminal boxes can accommodate support rails and KL mounting plates, thanks to the flexible 6.25 mm pitch pattern of installation holes

## Silicone gasket

- The joint free silicon gasket seals the entire perimeter of the door
- Easy to replace and inspect
- Guides and fixes the lid to the screw fasteners
- Compliant with FDA Guideline 21 CFR 177.2600

## Interior configuration

- Hole pitch of 6.25 mm for greater flexibility
- KL support rails and mounting plates can be fitted directly

## Hinges and gasket

- Hinges that are inside the sealing zone create an exceptionally easy-clean design on the outside
- The joint free silicon gasket seals the entire perimeter of the door
- Installed gaskets are easy to replace
- No external cavity between enclosure and door
- Gasket dyed blue to clearly distinguish it from food particles

## Screw fastener

- Captive
- With external gasket
- Hexagon shape for perfect cleanliness



## Lock and lock insert

- External parts made of stainless steel
- Material and shape allow easy and reliable cleaning

## External Angles

- The roof angled forwards by  $30^\circ$  on compact enclosures prevents objects from being deposited on it
- All-around tilt for terminal boxes
  - Enclosure:  $3^\circ$
  - Lid:  $10^\circ$
- Is easily inspected
- Allows fluids to drain off rapidly





**Design:**  
 - All four sides have 3° slope from back to front  
 - Captive fasteners keep them from falling out when removing cover

**Material:**  
 - Enclosure and cover: Stainless steel 1.4301 (AISI 304) 1.5mm  
 - Mounting bracket: Sheet steel, zinc-plated, passivated, 2.0mm  
 - Screw plug: Stainless steel  
 - Gasket: Silicone, compliant with FDA Guideline 21 CFR 177.2600

**Surface finish:**  
 - Enclosure and cover: Brushed grain 400, peak-to-valley height <0.8µm  
 - Gasket: Blue, dyed (RAL 5010)


**Protection category IP to IEC 60 529:**  
 - IP 66  
 - IPX 9

**Protection category IP to DIN 40 050-9:**  
 - IP 69K

**Protection category NEMA:**  
 - NEMA 13  
 - NEMA 4X  
 - NEMA 3R

**Supply includes:**  
 - Enclosure of all-around solid construction  
 - Cover  
 - Mounting bracket (pre-assembled)  
 - Gasket and screw plug (supplied loose)

**Approvals:**  
 - UL  
 - cUL



**Design:**  
 - All four sides have 3° slope from back to front  
 - Captive fasteners keep them from falling out when removing cover

**Material:**  
 - Enclosure and cover: Stainless steel 1.4301 (AISI 304) 1.5mm  
 - Mounting bracket: Sheet steel, zinc-plated, passivated, 2.0 mm  
 - Screw plug: Stainless steel  
 - Gasket: Silicone, compliant with FDA Guideline 21 CFR 177.2600

**Surface finish:**  
 - Enclosure and cover: Brushed, grain 400, peak-to-valley height < 0.8 µm  
 - Gasket: Blue, dyed (RAL 5010)


**Protection category IP to IEC 60 529:**  
 - IP 66  
 - IPX 9

**Protection category IP to DIN 40 050-9:**  
 - IP 69K

**Protection category NEMA:**  
 - NEMA 13  
 - NEMA 4X  
 - NEMA 3R

**Supply includes:**  
 - Enclosure of all-around solid construction  
 - Cover  
 - Mounting bracket (pre-assembled)  
 - Gasket and screw plug (supplied loose)

**Approvals:**  
 - UL  
 - cUL



## Push Buttons

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.	in.	mm.	PG
Height (front) (H1)		4	100	4	100	4	100	4	100	6	160	
Height (rear) (H2)		5	122	5	122	5	122	5	122	7	182	
Width (front) (B1)		4	100	6	160	9	220	11	280	9	220	
Width (rear) (B2)		5	122	7	182	10	242	12	302	10	242	
Depth (T)		4	90	4	90	4	90	4	90	4	90	
Model No.	1 pc(s).	1681.600		1682.600		1683.600		1684.600		1686.600		
Model Name		PB01225HD14		PB02225HD14		PB03225HD14		PB04225HD14		PB06225HD24		
Weight lbs.   kg		2.16	0.98	2.87	1.3	3.57	1.62	4.37	1.98	4.67	2.12	

## Accessories

HD wall spacer bracket		see page	21
HD cable gland		see page	26

## Depth: 3 - 5" (80 - 120 mm), Height-Rear: 7 - 13" (172 - 327mm)


	Packs of	in.	mm.	PG										
Height (front) (H1)		6	150	6	150	8	200	8	200	8	200	12	300	
Height (rear) (H2)		7	172	7	177	9	227	9	227	9	227	13	327	
Width (front) (B1)		6	150	6	150	8	200	12	300	16	400	16	400	
Width (rear) (B2)		7	172	7	177	9	227	13	327	17	427	17	427	
Depth (T)		3	80	5	120	5	120	5	120	5	120	5	120	
Model No.	1 pc(s).	1670.600		1671.600		1672.600		1674.600		1675.600		1676.600		
Model Name		HD060603N4		HD060605N4		HD080805N4		HD081205N4		HD081605N4		HD121605N4		
Weight lbs.   kg		4	1.7	5	2.2	7	3	9	4	11	5	13	5.9	

## Accessories

HD wall spacer bracket		see page	21				
Mounting plates	1 pc(s).	1560.700	1561.700	1562.700	1563.700	1564.700	1568.700
Support rails TS 35/7.5	10 pc(s).	2314.000	2314.000	2315.000	2316.000	2317.000	2317.000
HD cable gland		see page	26				

# Hygienic Design: Single Door Enclosures

# Hygienic Design: Single Door Enclosures



**Design:**

- Roof sloped 30° back to front.
- Overhanging roof shields top of gasket
- Gasket fills gap between door and enclosure body
- Internal hinges

**Material:**

- Enclosure and cover: Stainless steel 1.4301 (AISI 304) 1.5mm
- Mounting bracket: Sheet steel, zinc-plated, passivated, 2.0 mm
- Screw plug: Stainless steel
- Gasket: Silicone, compliant with

FDA Guideline  
21 CFR 177.2600

**Surface finish:**

- Enclosure and cover: Brushed, grain 400, peak-to-valley height < 0.8 µm
- Gasket: Blue, dyed (RAL 5010)

**Protection category IP to IEC 60 529:**

- IP 66
- IPX 9

**Protection category IP to DIN 40 050-9:**

- IP 69K

**Protection category NEMA:**


- NEMA 13
- NEMA 4X
- NEMA 3R

**Supply includes:**

- Enclosure of all-around solid construction
- Door with inserted gasket
- Door hinged on the right, may be swapped to the left
- Mounting plate

**Approvals:**

- UL
- cUL



## Depth: 6 - 8" (155 - 210mm), Height: 14 - 17" (350 - 430mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.
Height (front) (H1)		14	350	17	430	17	430	17	430
Height (rear) (H2)		17	437	22	546	22	549	22	549
Width (B)		9	220	12	310	15	390	32	810
Depth (T)		6	155	8	210	8	210	8	210
Mounting plate height		11	275	14	355	14	355	14	355
Mounting plate width		6	162	10	250	13	330	30	750
<b>Model No.</b>	1 pc(s).	<b>1302.600</b>		<b>1304.600</b>		<b>1306.600</b>		<b>1314.600</b>	
<b>Model Name</b>		<b>HD120806N4</b>		<b>HD151208N4</b>		<b>HD151508N4</b>		<b>HD153208N4</b>	
Weight lbs.   kg		14.55	6.6	24.25	11	32.41	14.7	56.22	25.5

## Depth: 8" (210mm), Height: 22 - 37" (430 - 810mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.	in.	mm.
Height (front) (H1)		22	550	22	550	26	650	26	650	32	810
Height (rear) (H2)		26	669	26	669	30	769	30	769	37	929
Width (B)		15	390	20	510	15	390	24	610	24	610
Depth (T)		8	210	8	210	8	210	8	210	8	210
Mounting plate height		19	475	19	475	23	575	23	575	29	730
Mounting plate width		13	330	18	450	13	330	22	550	22	550
<b>Model No.</b>	1 pc(s).	<b>1305.600</b>		<b>1307.600</b>		<b>1308.600</b>		<b>1310.600</b>		<b>4000.012</b>	
<b>Model Name</b>		<b>HD201508N4</b>		<b>HD202008N4</b>		<b>HD241508N4</b>		<b>HD242408N4</b>		<b>HD302408N4</b>	
Weight lbs.   kg		38.58	17.5	43.43	19.7	39.46	17.9	60.41	27.4	70.55	32

## Depth: 12" (300 mm), Height: 17 - 32" (430 - 810mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.
Height (front) (H1)		17	430	26	650	26	650	32	810
Height (rear) (H2)		24	601	32	821	32	821	39	981
Width (B)		24	610	24	610	32	810	24	610
Depth (T)		12	300	12	300	12	300	12	300
Mounting plate height		14	355	23	575	23	575	29	735
Mounting plate width		22	550	22	550	30	750	22	550
<b>Model No.</b>	1 pc(s).	<b>1320.600</b>		<b>1311.600</b>		<b>1315.600</b>		<b>1312.600</b>	
<b>Model Name</b>		<b>HD152412N4</b>		<b>HD242412N4</b>		<b>HD243212N4</b>		<b>HD302412N4</b>	
Weight lbs.   kg		47.84	21.7	68.34	31	85.98	39	83.78	38

## Depth: 12" (300 mm), Height: 32 - 43" (810 - 1100mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.
Height (front) (H1)		32	810	37	950	41	1050	43	1100
Height (rear) (H2)		39	981	44	1120	48	1221	50	1270
Width (B)		30	760	37	940	32	810	37	940
Depth (T)		12	300	12	300	12	300	12	300
Mounting plate height		29	735	34	871	38	955	40	1021
Mounting plate width		28	705	35	879	29	739	35	879
<b>Model No.</b>	1 pc(s).	<b>4000.014</b>		<b>1330.600</b>		<b>1316.600</b>		<b>1331.600</b>	
<b>Model Name</b>		<b>HD303012N4</b>		<b>HD363612N4</b>		<b>HD403212N4</b>		<b>HD423612N4</b>	
Weight lbs.   kg		74.96	34	132.28	60	132.5	60.1	148.81	67.5

## Depth: 12 - 18" (300 - 450mm), Height: 49 - 62" (1250 - 1575mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.
Height (front) (H1)		49	1250	50	1270	62	1575	61	1550
Height (rear) (H2)		56	1421	57	1440	69	1745	71	1804
Width (B)		32	810	37	940	37	940	36	910
Depth (T)		12	300	12	300	12	300	18	450
Mounting plate height		45	1155	47	1191	59	1496	59	1505
Mounting plate width		29	739	35	879	35	879	33	840
<b>Model No.</b>	1 pc(s).	<b>1317.600</b>		<b>1332.600</b>		<b>1333.600</b>		<b>1334.600</b>	
<b>Model Name</b>		<b>HD483212N4</b>		<b>HD483612N4</b>		<b>HD603612N4</b>		<b>HD603618N4</b>	
Weight lbs.   kg		156.53	71	168.65	76.5	276.02	125.2	285.06	129.3

### Accessories

			PG
HD wall spacer bracket		see page	21
HD cable gland		see page	26
HD hinge	2 pc(s).	see page	20
Rails for interior installation	4 pc(s).	see page	24
HD T-handle	1 pc(s).	see page	20
HD cam lock		see page	19
HD pressure release		see page	21

# Hygienic Design: Double Door Enclosures



### Design:

- Roof sloped 30° back to front.
- Overhanging roof shields top of gasket
- Gasket fills gap between door and enclosure body
- Internal hinges

### Material:

- Enclosure and cover: Stainless steel 1.4301 (AISI 304) 1.5mm
- Mounting bracket: Sheet steel, zinc-plated, passivated, 2.0 mm
- Screw plug: Stainless steel
- Gasket: Silicone, compliant with

FDA Guideline  
21 CFR 177.2600

### Surface finish:

- Enclosure and cover: Brushed, grain 400, peak-to-valley height < 0.8 µm
- Gasket: Blue, dyed (RAL 5010)

### Protection category IP to IEC 60 529:

- IP 66
- IPX 9

### Protection category IP to DIN 40 050-9:

- IP 69K

### Protection category NEMA:


- NEMA 13
- NEMA 4X
- NEMA 3R

### Supply includes:

- Enclosure of all-around solid construction
- Door with inserted gasket
- Door hinged on the right, may be swapped to the left
- Mounting plate

### Approvals:

- UL
- cUL



Depth: 16" (400mm), Height: 41 - 49" (1050 - 1250mm)


	Packs of	in.	mm.	in.	mm.	PG
Height (front) (H1)		41	1050	49	1250	
Height (rear) (H2)		50	1277	58	1477	
Width (B)		40	1010	40	1010	
Depth (T)		16	400	16	400	
Mounting plate height		37	945	46	1175	
Mounting plate width		37	945	37	945	
Model No.	1 pc(s).	1318.600		1319.600		
Model Name		HD404016N4		HD484016N4		
Weight lbs.   kg		1810	821.1	204	92.5	

### Accessories

PG

Accessories			PG
HD wall spacer bracket		see page	21
HD cable gland		see page	26
HD hinge	2 pc(s).	see page	20
Rails for interior installation	4 pc(s).	see page	24
HD T-handle	1 pc(s).	see page	20
HD cam lock		see page	19
HD pressure release		see page	21

# Hygienic Design: Junction Boxes



### Material:

- Enclosure and cover: Stainless steel 1.4301 (AISI 304)
- Seal: Silicone, compliant with FDA Guideline 21 CFR 177.2600

### Surface finish:

- Enclosure and cover: Brushed, grain 400, peak-to-valley height < 0.8 µm
- Seal: Blue, dyed (RAL 5010)

### Protection category IP to IEC 60 529:

- IP 66

### Protection category IP to DIN 40 050-9:

- IP 69K

### Protection category NEMA:


- NEMA 13
- NEMA 4X
- NEMA 3R

### Supply includes:

- Roof angled forwards by 3°
- Enclosure of all-around solid construction
- Door with inserted seal
- Door hinged on the right, may be swapped to the left

### Approvals:

- UL
- cUL



Depth: 12 - 18" (300 - 450mm), Height: 49 - 62" (1250 - 1575mm)

	Packs of	in.	mm.	in.	mm.	in.	mm.	in.	mm.	PG
Height (front) (H1)		8.6	219	11.4	290	8.7	220	8.7	220	
Height (rear) (H2)		9	229	11.9	302	8.7	220	8.7	220	
Width (B)		8.1	205	12	305	16.1	460	28	710	
Depth (T)		8.3	210	10.1	255	8.4	210	8.4	210	
Model No.	1 pc(s).	4000.021		4000.022		4000.031		4000.032		
Model Name		HD090808H4		HD111210H4		HD091808H4		HD092808H4		
Weight lbs.   kg		10	4.5	18	8.2	38	17.2	83	37.6	

### Accessories

PG

Accessories			PG
HD wall spacer bracket		see page	21
HD cable gland		see page	26
HD hinge	2 pc(s).	see page	20
Rails for interior installation	4 pc(s).	see page	24
HD T-handle	1 pc(s).	see page	20
HD cam lock		see page	19
HD pressure release		see page	21

# Hygienic control and monitoring

Command panels and printer enclosures play a key role in the decentralized control and monitoring of open processes in the food and beverage industry. Their functional design means that standard commercially available PC components such as printers, monitors, and label printers are easily and securely integrated into the production process. Can be used together or separately for machine controls, monitoring, programming, creating kiosks, and other applications.



## Silicone gasket

- The joint free silicon gasket seals the entire perimeter of the door
- Easy to replace and inspect
- Compliant with FDA Guideline 21 CFR 177.2600
- Gasket dyed blue to clearly distinguish it from food particles



## Easy monitoring

- Large visible area with inset and sealed polycarbonate window in the door
- Screwed-fastened mounting plate with holes for VESA 75 and 100 connection
- Attachment of monitors of up to 24"



## User-friendly design

- Enclosure tilted forwards by 3° – to allow liquids to drain off reliably whilst cleaning – for the support of keyboards during production
- Component shelves with telescopic slides for easy integration of computers or e.g. label printers
- Interior installation rails allow the installation of additional component shelves



## Modular combination

- Connection component for combining a command panel and a printer enclosure into a complete PC enclosure
- Integral drilled holes with a diameter of 40 mm for easy cable entry with connectors



# Hygienic Design: Production Data Cabinet



**Material:**  
 - Stainless steel 1.4301 (AISI 304)  
 Enclosure: 1.5 mm  
 Door: 2.0 mm  
 - Lock inserts: Stainless steel 1.4301 (AISI 304)  
 - Gasket: Silicone, compliant with FDA Guideline 21 CFR 177.2600


**Surface finish:**  
 - Brushed, grain 400,  $R_a < 0.8 \mu\text{m}$   
 - Gasket: Blue, dyed (RAL 5010)

**Protection category IP to IC 60 529:**  
 - Enclosure top: IP 66  
 - Enclosure bottom: IP 66


**Protection category IP to DIN 40 050-9:**  
 - Enclosure top: IP 59K  
 - Enclosure bottom: IP 69K

**Console supply includes:**  
 - Roof angled forwards by 30°  
 - Door with integrated polycarbonate pane for monitor; compartment with screw-fastened mounting plate with holes for VESA connection 75 and 100  
 - Viewing window: polycarbonate  
 - Mounting plate height-adjustable for screens up to 24"

**Pedestal supply includes:**  
 - Roof angled forwards by 3°, suitable as a support rest or for keyboard installation  
 - Component shelf spray-finished, pull-out and height-adjustable with side punched rails



## HD production data cabinet, modular



	Packs of	in.	mm.	in.	mm.	PG
<b>Height (front) (H1)</b>		27	692	34	863	
<b>Height (rear) (H2)</b>		33	848	35	888	
<b>Width (B)</b>		32	810	32	810	
<b>Depth (T)</b>		10	266	20	496	
<b>Model No.</b>	1 pc(s).	4000.062		4000.006		
Weight lbs.   kg		73	33.2	119	54.2	

### Accessories

HD keyboard support	1 pc(s).	see page	22
HD wall spacer bracket		see page	21
HD hinge	2 pc(s).	see page	20
HD cable gland		see page	26
HD connection components (for combining enclosures together)	1 pc(s).	see page	21
HD T-handle	1 pc(s).	see page	20
HD flap	1 pc(s).	see page	22
HD leveling feet		see page	19

# Hygienic Design: Fire Extinguisher Enclosure



**Design:**  
 - Roof angled forwards by 30°

**Benefits:**  
 - Hygienic, hose-proof storage of fire extinguishers  
 - Time and cost savings thanks to simple, effective cleaning options  
 - Fire extinguisher is easily removed with one hand thanks to the T-handle  
 - Quick inventory check with the integral viewing door  
 - Additional uses include storage of first aid kits and defibrillators


**Material:**  
 - Enclosure and door: Stainless steel 1.4301 (AISI 304)  
 - Handle and lock: Stainless steel 1.4301 (AISI 304)  
 - Viewing window: Polycarbonate  
 - Gasket: Silicone, compliant with FDA Guideline 21 CFR 177.2600

**Surface finish:**  
 - Enclosure and door: Brushed, grain 400, peak-to-valley height < 0.8  $\mu\text{m}$   
 - Gasket: Blue, dyed (RAL 5010)

**Protection category IP to IEC 60 529:**  
 - IP 66

**Protection category IP to DIN 40 050-9:**  
 - IP 59K

**Supply includes:**  
 - Enclosure of all-around solid construction  
 - Door with viewing window and inserted gasket  
 - Interchangeable door hinge  
 - T-handle with 3-point lock system



## Fire extinguisher enclosure HD

	Packs of	in.	mm.	in.	mm.	PG
<b>Height (front) (H1)</b>		26	650	34	863	
<b>Height (rear) (H2)</b>		30	769	35	888	
<b>Width (B)</b>		12	300	32	810	
<b>Depth (T)</b>		8	210	20	496	
Viewing window width		5	120	7	190	
Viewing window height		19	482	26	670	
<b>Model No.</b>	1 pc(s).	4000.073		4000.075		
Weight lbs.   kg		30	13.5	49	22	

### Accessories

HD wall spacer bracket		see page	21
HD hinge		see page	20

# Air/Water Heat Exchangers Hygienic Design



An easy-to-clean enclosure climate control solution is now available for hygiene-critical production zones in the food and beverage industry.

- Hygienic design simplifies cleaning procedures and guarantees food safety
- Protection category IP 56/59 if correctly fitted – suitable for high-pressure and steam-jet cleaning
- Enclosure made from 1.4301 (AISI 304) stainless steel with the roof tilted forwards by 30°
- Water connections made from stainless steel 1.4301 (AISI 304)
- Suitable for use in the food industry to DIN EN 1672-2:2009



## Hygienic Design: Air/Water Heat Exchanger



Air/water heat exchanger for hygienically sensitive production zones in the food and beverage industry – the optimum addition to the Rittal Hygienic Design range. The cleaning-friendly design reduces the risk of contamination and ensures food safety.

- Benefits:**
- Easy-to-clean, hygienic design
  - A roof tilt of 30° prevents objects from being deposited on it, and allows liquids to run off quickly.
  - All-around external, replaceable silicone gasket prevents the accumulation of dirt between the enclosure and the air/water heat exchanger.

**Material:**

- Enclosure and cover: Stainless steel 1.4301 (AISI 304)

**Surface finish:**

- Enclosure: Brushed, grain 400, peak-to-valley height < 0.8 µm

**Protection category IP to IEC 60 529:**

- IP 56/59

**Protection category NEMA:**

- NEMA 4X

**Cooling medium:**

- Water (see internet for specifications)

**Supply includes:**

- Fully wired ready for connection (plug-in terminal strip)
- Drilling template
- Sealing and assembly parts

**Note:**

- To achieve a protection category of IP 66/59 to IEC 60 529, the ingress of leakage air through the condensate discharge opening must be completely prevented.

### HD Air / Water Heat Exchanger

<b>Total cooling output L35 W10, 200 i/h (kW)</b>	<b>2047 BTU (0.6)</b>		<b>3412 BTU (1)</b>	
<b>Total cooling output L35 W10, 400 i/h (kW)</b>	<b>2217 BTU (0.65)</b>		<b>4095 BTU (1.2)</b>	
Temperature control	Thermostat-controlled magnetic valve		■	
Power consumption Pel 50/60 Hz W	36/37		83/85	
Rated operating voltage V, ~, HZ	230, 1 ~, 50/60		230, 1 ~, 50/60	
	in.	mm.	in.	mm.
<b>Height</b>	<b>21</b>	<b>526</b>	<b>39</b>	<b>982</b>
<b>Width</b>	<b>9</b>	<b>220</b>	<b>8</b>	<b>215</b>
<b>Depth</b>	<b>4</b>	<b>100</b>	<b>4</b>	<b>100</b>
Rated current max. A	0.16 / 0.14		0.38 / 0.47	
Pre-fuse A	2		4	
Operating temperature range	+34°F...+158°F (+1°C...+70°C)		+34°F...+158°F (+1°C...+70°C)	
Setting range	+68°F...+140°F (+20°C...+60°C)		+68°F...+140°F (+20°C...+60°C)	
Water inlet temperature	+34°F...+86°F (+1°C...+30°C)		+34°F...+86°F (+1°C...+30°C)	
Water connection	G 3/8" external thread		■	
Permissible operating pressure (p.max.) bar	14-145 PSI (1-10)		14-145 PSI (1-10)	
Air throughout of fans (unimpeded air flow), Internal circuit 50/60 HZ m³/h	164 / 182 CFM (280 / 310)		400 / 432 CFM (680 / 735)	
<b>Model No.</b>	<b>3214.700</b>		<b>3215.700</b>	
Weight lbs.   kg	13	6	31	14



## HD leveling feet

For HD system enclosure and HD compact enclosure.

### Benefits:

- Minimizes cleaning time thanks to fully covered permanently sealed threads
- Compensation of floor inclines up to an angle of 10° thanks to flexible base
- Baying can even be achieved on sloping floors,

thanks to a large leveling range  
– Design to EHEDG standards

### Material:

- Stainless steel 1.4301 (AISI 304)

### Load capacity:

- Max. 7000 N static per leveling foot

### Supply includes:

- Assembly parts and seals

HD leveling feet

Design	Packs of	Without base mount		With base mount	
		M12		M12	
Thread		in.	mm.	in.	mm.
Adjustment range		4.8 – 6.9	122 – 175	4.8 – 6.9	122 – 175
Model No.	4 pc(s).	4000.240		4000.250	



## HD cam lock

Options to replace current HD enclosure lock.

### Applications:

- In case a different contour is required or an option with metal tongue, please use 9980.111 to replace the standard lock that comes with your HD enclosure
- To replace the standard lock, please use 5050.613

### Material:

- Stainless steel

HD cam lock

	Packs of		
Model No.	1 pc(s).	9980.111	5050.613



## HD enclosure key

For HD cam lock.

### Note:

- Enclosure, case, and lock systems are supplied as standard with matching keys

HD enclosure key

	Packs of	
Model No.	1 pc(s).	2549.00

## HD bit

for universal key 2549.500.

HD bit

	Packs of	Without key lock
Model No.	1 pc(s).	2549.510



## HD T-handle

For easy opening without a key. May be exchanged in all enclosures with cam lock.

### Material:

- Stainless steel 1.4301 (AISI 304)

HD T-handle

Design	Packs of	Without key lock	With key lock
Model No.	1 pc(s).	4000.065	4000.067



## HD hinge

To be used in exchange in HD enclosures with internal hinges.

### Material:

- Stainless steel 1.4301 (AISI 304)

### Supply includes:

- Assembly parts

HD hinge

	Packs of	
Model No.	2 pc(s).	4000.130





## HD wall spacer bracket

### Benefits:

- Creates space for cleaning behind the enclosure
- Shorter assembly times by eliminating the need for an all-round seal
- Improved hygiene by avoiding inaccessible dead spaces or gaps between the enclosure wall
- Rated UL Type 4X and IP69

### Material:

- Stainless steel 1.4301 (AISI 304)

### Supply includes:

- Assembly parts and seals

### Note:

- Depending on the size of the enclosure, up to 4 wall spacer brackets are required to ensure sufficiently stable wall mounting

HD wall spacer bracket

	Packs of	in.	mm.	in.	mm.
<b>Height</b>		2	50.8	1.9	50
Design specifications		no pass through		pass through	
<b>Model No.</b>	1 pc(s).	<b>9957.334</b>		<b>4000.100</b>	



## HD connection components

For combining HD command panels (4000.062) and HD printer enclosures (4000.064) into one PC enclosure.

### Material:

- Console: Stainless Steel 1.4301 (AISI 304)

### Supply includes:

- 2 reinforcement plates for enclosure, top
- 4 reinforcement plates for enclosure, bottom (2 for the roof, 2 for the attachment of leveling feet or supporting structure)
- 2 spacer supports with drilled hole Ø 40 mm for cable entry, height 50/45.8 mm

HD connection components

	Packs of	
<b>Model No.</b>	1 pc(s).	<b>4000.066</b>



## HD pressure release

The integrated sealing membrane in pressure relief plugs largely prevents these pressure differences and the build-up of condensate, as well as protecting against the penetration of moisture from outside.

### Supply includes:

- Lock Nut

### Material:

- Sheet steel 1.4301 (AISI 304)

### Technical Specifications:

- Connection thread M12 X 1.5
- Air permeability up to 60 liters / hour with a pressure difference of 70 mbar

### Approvals:

- UL Type 4X
- IP 66 / IP69

HD pressure release

	Packs of	
<b>Model No.</b>	1 pc(s).	<b>4000.300</b>

## HD keyboard support

To support standard keyboards, including water drain hole.

### Material:


- Stainless steel 1.4301 (AISI 304)

### Supply includes:

- Spacer support to the enclosure

HD keyboard support

	Packs of	in.	mm.
<b>Width</b>		23	573
<b>Depth</b>		10	250
Contact surface width		22	570
Contact surface depth		7	190
<b>Model No.</b>	1 pc(s).	<b>4000.072</b>	



## HD flap

For rapid access e.g. in order to change the labels.

### Supply includes:

- T-handle
- Silicon gasket
- Hinges and cam lock

### Material:

- Sheet steel 1.4301 (AISI 304)

HD hinge

	Packs of	
<b>Model No.</b>	1 pc(s).	<b>4000.068</b>

# Hygienic Design: Accessories



## Hose-proof hood

### To increase the protection category

For fan-and-filter units/outlet filters. Easy cleaning thanks to exterior silicone gasket compliant with FDA Guideline 21 CFR 177.2600.

#### Material:

- Stainless steel
- Silicone

### Protection category IP to IEC 60 529:

- IP 56 when fitted over fan-and-filter unit/outlet filter with filter mat



To fit Model No.	W x H x D in. (mm)	Protection category	Packs of	Model No.
3237...	5.9" x 9" x 1.5" (150 x 230 x 40)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R	1 pc(s).	3237.080
3238...	6.9" x 9.6" x 2.1" (176 x 245 x 55)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R NEMA 4 NEMA 4X	1 pc(s).	3238.080
3239...	9.1" x 12.9" x 2.1" (233 x 330 x 55)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R NEMA 4 NEMA 4X	1 pc(s).	3239.080
3240.../3241...	11.1" x 15.3" x 3.3" (282 x 390 x 85)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R NEMA 4 NEMA 4X	1 pc(s).	3240.080
3243.../3244...	13.7" x 18.8" x 4.3" (350 x 480 x 110)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R NEMA 4 NEMA 4X	1 pc(s).	3243.080
3245...	13.7" x 18.8" x 6.2" (350 x 480 x 160)	NEMA 1 NEMA 12 NEMA 3 NEMA 3R	1 pc(s).	3245.080

# Hygienic Design: Accessories



## Rails for interior installation

### For HD compact installation

For mounting on the existing threaded bolts. With TS system punchings on three sides.


#### Material:

- Sheet steel, zinc-plated

#### Supply includes:


- Assembly parts

Length in. (mm)	Packs on	Model No.
20" (510)	4 pc(s).	5001.050
27.9" (710)	4 pc(s).	5001.051
35.8" (910)	4 pc(s).	5001.052
43.7" (1110)	4 pc(s).	5001.053




### Interior installation door

Enclosure	1	1	1
Model No.	Model No.		
1316.600	5001.052	5001.050	5001.050
1317.600	5001.053	5001.051	5001.051
		5001.050	5001.050



### Interior installation door

Enclosure	1	2	3
	Rails for interior installation 	TS punched section with mounting flange 17 x 73 mm 	Mounting plates 
Model No.	Model No.	Model No.	
1308.600 1310.600 1315.600	5001.050	-	-
1316.600	5001.052	8612.130 (only on lock side)	8612.400 8612.410
1317.600	5001.053	8612.130 (only on lock side)	8612.400 8612.410



## Replacement Gaskets

Spare Gasket	Fits Enclosure Model No.
5050.631	1302.600
5050.855	1304.600
5050.630	1306.600
5050.623	1314.600
5050.856	1305.600
5050.628	1307.600
5050.629	1308.600
5050.626	1310.600
5050.627	1320.600
5050.857	1311.600
5050.622	1315.600
5050.858	1312.600
5050.625	1316.600
5050.624	1317.600
5050.688	1318.600
5050.669	1319.600

## HD cable gland

### Applications:

- Food and beverage production
- Clean room technology (e.g. pharmaceuticals)
- Biotechnology
- Chemical industry

### Benefits:

- Smooth, solid exterior surfaces effectively prevent the depositing of harmful micro-organisms
- Much easier to clean, making it cost effective, compared with conventional cable glands
- EMC version enables cable shield bonding

### Material:

- Lock nut: Stainless steel 1.4305 (AISI 303)
- Gasket: Conforms to FDA 21 CFR 177.2600

### Protection category IP to DIN 40 050-9:

- IP 69K

### Supply includes (per pack):

- 5 cable glands
- 5 lock nuts

### Metric Version


Size	Packs of	M12 X 1.5		M16 X 1.5		M20 X 1.5		M25 X 1.5	
		in.	mm.	in.	mm.	in.	mm.	in.	mm.
Cable diameter		0.12 – 0.26	3 – 6.5	0.20 – 0.39	5 – 10	0.24 – 0.47	6 – 12	0.47 – 0.67	12 – 17
Model No.	5 pc(s).	2410.001		2410.011		2410.021		2410.031	

### Metric EMC Version

Size	Packs of	M16 X 1.5		M20 X 1.5		M25 X 1.5	
		in.	mm.	in.	mm.	in.	mm.
Cable diameter		0.20 – 0.39	5 – 10	0.24 – 0.47	6 – 12	0.47 – 0.67	12 – 17
Model No.	5 pc(s).	2410.111		2410.121		2410.131	

### MetricNPT Version

Size	Packs of	NPT 1/4"		NPT 3/8"		NPT 1/2"		NPT 3/4"	
		in.	mm.	in.	mm.	in.	mm.	in.	mm.
Cable diameter		0.20 – 0.26	5 – 6.5	0.24 – 0.39	6 – 10	0.35 – 0.53	9 – 13.5	0.55 – 0.71	14 – 18
Model No.	1 pc(s).	9957.640		9957.641		9957.642		9957.643	




- 1 Gasket
- 2 Cap nut
- 3 Gripper jaws
- 4 Shield spring (EMC version only)
- 5 Clamping ring
- 6 Enclosure gasket
- 7 Base with locator for assembly tool

## Why use hygiene-compatible cable glands


### Critical points with conventional solutions

- 1 Cable entry in front of gasket
- 2 No minimum radii on the hexagon
- 3 External threads
- 4 Gap caused by O-ring on the enclosure surface



### Hygiene-compatible design features

- 1 Gasket directly at the cable entry
- 2 Compliance with minimum radii on the hexagon
- 3 No external threads
- 4 Flush termination between the cap nut and the enclosure



## Assembly tool

For HD cable gland tool, for attaching cable glands in an internal thread or using lock nuts. This can be achieved either from the inside or


from the outside using an Allen key

### Supply includes (per pack):

- One (1) pc(s). Adapter for sizes M12 – M25

### Assembly tool

Model No.	Packs of	
	1 pc(s).	2410.290



# Rittal – The System.

**Faster – better – everywhere.**

- Enclosures
- Power Distribution
- Climate Control
- IT Infrastructure
- Software & Services

## **Rittal North America LLC**

Woodfield Corporate Center  
425 North Martingale Road, Suite 400 • Schaumburg, Illinois 60173 • USA  
Phone: 937-399-0500 • Toll-free: 800-477-4000  
Email: [rittal@rittal.us](mailto:rittal@rittal.us) • Online: [www.rittal.com](http://www.rittal.com)

## **Rittal Systems Ltd.**

6485 Ordan Drive • Mississauga, Ontario L5T 1X2 • Canada  
Phone: 905-795-0777 • Toll-free: 800-399-0748  
E-Mail: [marketing@rittal.ca](mailto:marketing@rittal.ca) • Online: [www.rittal.ca](http://www.rittal.ca)

## **Rittal Mexico**

Dr. Roberto Gayol 1219-1B • Col. Del Valle Sur, 03100 • Mexico, D.F.  
Phone: (+52) (55) 5559-5369 • Toll-free: 01 800 8 Rittal (748.825)  
E-Mail: [info@rittal.com.mx](mailto:info@rittal.com.mx) • Website: [www.rittal.com.mx](http://www.rittal.com.mx)

US350-BR-TR ■ 6/22

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES

